

## LIFEJACKET LIGHT TYPE

### “RESCUE-DAN M”, “RESCUE-DAN M1” & “RESCUE-DAN MR”

#### Operation, Maintenance & Service Instructions

#### **Operation**

Turn the glass clockwise and the light will illuminate (flash).  
If the light is fitted with a cord and pull ring, activate the light by pulling the ring.  
The light can be turned off by rotating the glass anti clockwise.

#### **Maintenance**

The power source is maintenance free lithium battery with a shelf life of min. 5 years.  
The glass must not be unscrewed by excess force.  
The complete light can only be replaced as one unit.  
The expiry (replacement) date is indicated on the label by month & year.

#### **Service intervals**

It is recommended to activate the light for 1 minute during periodical surveys.  
Inspect the light for deterioration.  
Replace the light if found faulty.

#### **Safety Precautions**

- Do not dismantle the light assembly.
- Do not make any external electrical connection.
- Do not recharge.
- Do not incinerate.
- Store between -30°C to +65°C