

LIFEJACKET LIGHT TYPE

“RESCUE-DAN W”, “RESCUE-DAN W1” & RESCUE-DAN WR”

Operation, Maintenance & Service Instructions

Operation

The light will illuminate automatically, when in water.
The light can be turned off by rotating the glass anti clockwise.
The light can be reactivated by turning the glass clockwise.

Maintenance

The power source is maintenance free lithium battery with a shelf life of min. 5 years.
The glass must not be unscrewed by excess force.
The complete light can only be replaced as one unit.
The expiry (replacement) date is indicated on the label by month & year.

Service intervals

It is recommended to activate the light for 1 minute during periodical surveys. A paper clip may be applied to the 2 water contacts on topside of the light.
Inspect the light for deterioration.
Replace the light if found faulty.

Safety Precautions

- Do not dismantle the light assembly.
- Do not make any external electrical connection.
- Do not recharge.
- Do not incinerate.
- Store between -30°C to +65°C